

Custom Spacer/Bracket Template by BigSky2 c/o YarisWorld.com

Directions:

- 1: Outline Diameter of your speaker's MOUNTING DIAMETER using the center as your point of reference
2. Cut Outside Edge carefully
3. Cut Inside Circle that you drew in Step 1 carefully
4. Use a Bandsaw for the outside edge, and a jigsaw for the inside circle


HATCHBACK ONLY!

For Rear Door/Panel

Speaker

Stock Speaker Size: 5 1/4"

(roughly)



Directions:

- 1: Outline Diameter of your speaker's MOUNTING DIAMETER using the center as your point of reference
2. Cut Outside Edge carefully
3. Cut Inside Circle that you drew in Step 1 carefully
4. Use a Bandsaw for the outside edge, and a jigsaw for the inside circle

HATCHBACK ONLY!
For Front Door Speaker
Stock Speaker Size: 6.5"

